






Make	Model	Year	Bluetooth Switch
Infiniti 	FX35	2007-2008	NISBTSW2
	FX45	2007-2008	NISBTSW2
	G35	2007-2008	NISBTSW2
	M35	2007-2008	NISBTSW2
	QX56	2007-2008	NISBTSW2

Make	Model	Year	Bluetooth Switch
Lexus 	RX 350	2007-2008	TOYBTSW2

Make	Model	Year	Bluetooth Switch
Mazda 	CX7	2007-2008	MAZBTSW2
	CX9	2007-2008	MAZBTSW2
	Mazda 3	2007-2008	MAZBTSW2
	Mazda 6	2007-2008	MAZBTSW2
	RX-8	2007-2008	MAZBTSW2

Make	Model	Year	Bluetooth Switch
Mitsubishi 	Lancer	2007-2008	MITBTSW2
	Galant	2007-2008	MITBTSW2
	Outlander	2007-2008	MITBTSW2

Make	Model	Year	Bluetooth Switch
Nissan 	Altima	2007-2008	NISBTSW2
	Armada	2007-2008	NISBTSW2
	Frontier	2007-2008	NISBTSW2
	Pathfinder	2007-2008	NISBTSW2
	Sentra	2007-2008	NISBTSW2
	Titan	2007-2008	NISBTSW2
	Versa	2007-2008	NISBTSW2
	Xterra	2007-2008	NISBTSW2

Make	Model	Year	Bluetooth Switch
Toyota 	4Runner	2007-2008	TOYBTSW2
	Avalon	2007-2008	TOYBTSW3
	Camry	2007-2008	TOYBTSW3
	Corolla	2009	TOYBTSW2
	Highlander	2007-2008	TOYBTSW3
	Land Cruiser	2007-2008	TOYBTSW2
	FJ Cruiser	2007-2008	TOYBTSW2
	Matrix	2007-2008	TOYBTSW2
	Matrix	2009	TOYBTSW3
	RAV4	2007-2008	TOYBTSW3
	Prius	2007-2008	TOYBTSW3
	Sequoia	2007-2008	TOYBTSW2
	Sienna	2007-2008	TOYBTSW2
	Solara	2007-2008	TOYBTSW2
	Tacoma	2007-2008	TOYBTSW2
	Tundra	2007-2008	TOYBTSW3
	Yaris	2007-2008	TOYBTSW3
	Scion	XB	2007-2008
XD		2007-2008	TOYBTSW3
TC		2007-2008	TOYBTSW2